

Mobile Device Discovery Kit

New Jersey State Library

How to Reset a Kindle Fire

Before returning your Mobile Device Discovery Kit, we request that you please reset the Kindle Fire in order to wipe it clear of any data and settings that you have saved on the device.

Instructions are below.

1. Tap the **Settings Gear** in the upper-right corner.
2. Tap **More**.
3. Tap **Device**.
4. Select **Reset to Factory Defaults**.
5. Select **Erase Everything** to confirm that you would like to erase all data and settings from the Kindle Fire.

Thank you for your cooperation!